

FUNCTION VALUE	MODULE		DESCRIPTION	SOFTWARE
REAR LED CONVERSION				
BREMSLICHT_ALS_STANDLICHT	ALSZ	nicht_aktiv	the tail lights and break light is on well, to prevent the "t" effect, you just have to code your light co	NCSEXPERT
PWM_ANSTEUERUNG_SL_RE_HI	ALSZ	wert_01	flickering of taillight / 6V issue this gives 12v to the tail lights without further modications.	NCSEXPERT
PWM_ANSTEUERUNG_SL_LI_HI	ALSZ	wert_01	flickering of taillight / 6V issue this gives 12v to the tail lights without further modications.	NCSEXPERT
WARMUEBERWACHUNG_RL_LI	ALSZ	nicht_aktiv	just deactivate the checkcontrols to rear LEDs	NCSEXPERT
WARMUEBERWACHUNG_RL_RE	ALSZ	nicht_aktiv	just deactivate the checkcontrols to rear LEDs	NCSEXPERT
KALTUEBERWACHUNG_RL_RE	ALSZ	nicht_aktiv	just deactivate the checkcontrols to rear LEDs	NCSEXPERT
KALTUEBERWACHUNG_RL_LI	ALSZ	nicht_aktiv	just deactivate the checkcontrols to rear LEDs	NCSEXPERT
CC_RUECKLICHT_LINKS	ALSZ	nicht_aktiv	just deactivate the checkcontrols to rear LEDs	NCSEXPERT
CC_RUECKLICHT_RECHTS	ALSZ	nicht_aktiv	just deactivate the checkcontrols to rear LEDs	NCSEXPERT
ALARM / ANTI THEFT SYSTEM				
ALARM_OPT_ABBLENDLICHT	GM5	aktiv	Alarm Flash 1 - alarm flashes low beam when tripped	NCSEXPERT
ALARM_OPT_WARNBLINKER	GM5	aktiv	Alarm Flash 2 - emergency flasherswhen tripped	NCSEXPERT
ALARM_OPT_FERNLICHT	GM5	aktiv	Alarm Flash 2 - high beam when tripped	NCSEXPERT
QUIT_AKUST_ENTSCH	GM5	aktiv	Alarm beep on unlock	NCSEXPERT
QUIT_AKUST_SCHAERF	GM5	aktiv	Alarm beep on unlock	NCSEXPERT
INTERIOR SENSORS			Turn on or off sensors	SSS
TILT SENOR			Turn on or off sensors	SSS
VISUAL DISARMING			Turn on or off indicators flash	SSS
VISUAL ARMING			Turn on or off indicators flash	SSS
VISUAL ARIMING LIDS CLOSED			Turn on or off	SSS
LOCK & UNLOCK				
VERRIEGELN_AUT_AB_X_KMH	GM5	aktiv	automatic central locking afterX KMH	NCSEXPERT
VERRIEGELN_AUT_NACH_2_MIN	GM5	aktiv	automatic central locking is re-locked after 2 MIN if you dont open a door	NCSEXPERT
KOMFORTOEFFNUNG_FB	GM5	aktiv	convertible top opens by holding the open button on remote..Or opens all windows & sun roof on no	NCSEXPERT
KOMFORTSCHLIESSUNG_FB	GM5	aktiv	convertible top closes by holding the close button on remote..Or closes all windows &sun roof on no	NCSEXPERT
INTERIOR LIGHT			Turn on or off	SSS
OPEN TAILGATE			Turn on or off	SSS
LOCK AFTER UNLOCK WITHOUT OPEI			Turn on or off	SSS
LOCK AFTER DRIVE OFF			Turn on or off	SSS
DOUBLE UNLOCK WITH CENTERLOCK			Turn on or off	SSS
SLECTIVE CENTRAL LOCKING (KEYS)			Turn on or off	SSS
INDICATORS				
CYCL_TI_BLK	GM5		einmal-1 . zweimal-2 . dreimal-3. One touch indicators, lane change (Facelift model)	NCSEXPERT
1 TOUCH FUCTION TURN SIGNAL FLA			Turn on or off 1 X Flashing, 3 x Flashing (Facelift models)	SSS
BLINKIMPULS_CRASHBLK	ALSZ	change to to wert_04	Double Hazzards after crash	NCSEXPERT
BLINKIMPULS_WARNBLK	ALSZ	change to to wert_04	Double Hazzards	NCSEXPERT
LIGHTING				
HEIMLEUCHTEN_AL	ALSZ		home lights are low beam	NCSEXPERT
HEIMLEUCHTEN_FL	ALSZ		Home lights are high beams	NCSEXPERT
HEIMLEUCHTEN_KL58G	ALSZ		home lights are interior backlighting, cluster, ashtray etc	NCSEXPERT
HEIMLEUCHTEN_KZL	ALSZ		Home light is license place	NCSEXPERT
HEIMLEUCHTEN_NSW	ALSZ		home lights are front fogs	NCSEXPERT
INTERIOR LIGHT ON WITH UNLOCK			Turn on or off	SSS
INTERIOR LIGHT ON WITH TERM R Of			Turn on or off	SSS
SOFT ON/OFF			Turn on or off	SSS
DAYLIGHT RUNNING LIGHT ECE			Turn on or off	SSS
HOME LIGHTS, TIME PERIOD			Turn on or off, 40S 90S 150S 240Seconds	SSS

FUNCTION VALUE	MODULE	DESCRIPTION	SOFTWARE
AUTO DRIVE LIGHTS		Sensitive or normal	SSS
SEATS			
AUT_SITZVERSTELLUNG SEAT ADJUSTMENT	SM	choose between automatic seat adjustment when remote signals door open or when door opened After unlocking & door opening, after unlocking with remote, not active	NCSEXPERT SSS
WINDOWS			
TOUCH OPEN DRIVERS SIDE		Turn on or off	SSS
TOUCH OPEN PASSENGER SIDE		Turn on or off	SSS
WINDSCREEN WIPERS			
RAIN SENSOR		Turn on or off	SSS
ACOUSTIC WARNINGS			
IGNITION KEY WARNING		Turn on or off	SSS
HEATING - A/C - VENTILATION			
KEY SPECIFIC SET OF HEAT, AC, VEN FAN CORRECTION (KEY)		Turn on or off Increase, not active, decrease	SSS SSS
FLAPS SETPOINT CORRECTION (KEY)		+3, +2, +1, not active, -1, -2, -3 degrees	SSS
A/C OPERATION ON WITH IGNITION (Turn on or off	SSS
CLOSED FOOTWELL FLAP (KEY)		Turn on or off	SSS
RECIRCULATED AIR MEMORY		Turn on or off	SSS
DISPLAY / LANGUAGE			
CONSUMPTION		Litres/100km, mpg(uk), mpg(us), km/litre	SSS
DISTANCE		Kilometres, miles	SSS
TIME		12 hours, 24 hours	SSS
TEMPERATURE		Degrees celsius, degrees fahrenheit	SSS
AUDIO / VIDEO			
KEY SPECIFIC SETTINGS		Turn on or off	SSS
PDC			
SWITCH ON SIGNAL		Turn on or off	SSS
NCSEXPERT MODULES			
	ACSM	Airbag / seatbelt	
	DSP	DSP settings	
	EWS	Electronic Immobilizer	
	EPS	Sport button	
	GM5	Windows / locks / alarm / remote	
	GT	Nav	
	IHK	HVAC	
	KMB	Freeze Warning.oil / outside temp / inst cluster /ect	
	LSZ	Lights	
	LWS5	Car lists	
	MK60	ABS.Stability.DSC.steering	
	RA_NG	Radio Type	
	SM	seat memory	
	TCU	bluetooth.speed volume.	